

# PTE0230 Touch Keypad

## Installation Instructions

1. Unclip mounting case front.
2. Remove the blue non-stick covers from adhesive strips.
3. Remove the keypad from plastic wrapping. Ensure the back is clean and dust free.
4. Position the keypad directly in the centre of the case front with the top edge of the keypad in line with the top edge of the case front.  
Press the two together firmly and hold for 30 seconds.
5. Mount the case back to the wall using screws.
6. Screw the PAE223 USB-Keypad adapter into the case back with two self-tapping screws (MHF035).
7. Connect the USB cable and keypad bus cable to the PAE223. Plug the keypad power supply into a wall outlet.
8. Clip the keypad and case front onto the case back.
9. Connect the USB cable and power supply to the top of the keypad.
10. Press the power button of the keypad. The unit will start and present the home screen of the keypad. Access online help by pressing the 'Help' button in the top right corner of the screen.

