

PTE2273 PET Solar Kit Installation Instructions



1. Place the panel on the star picket



4. Attach battery leads to any lead acid battery



2. Secure with a cable tie (included)



3. Hang the PET Energizer and attach the DC power lead



5. Complete

JVA recommends using a standard car battery. Any lead acid battery can be used, however very small batteries (<10 Ahr) will not receive ideal charge conditions and may see a reduced life.